


# Kelachandra

## WELL RECHARGING SYSTEM

RECHARGE  
YOUR WELL  
REGAIN  
YOUR WATER  
SOURCE

## RAIN WATER HARVESTING & GUTTER SYSTEM




### PATHY PIPE

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wp14	bp14	rp14
180mm	wp18	bp18	rp18

### JOINT BRACKET

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wjb14	bjb14	rjb14
180mm	wjb18	bjb18	rjb18




### RUNNING OUTLET

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wro14	bro14	rro14
180mm	wro18	bro18	rro18

### 90 Deg ELBOW WITHOUT OUTLET

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wwo14	bwo14	rwo14
180mm	wwo18	bwo18	rwo18






### ◀ 90 Deg ELBOW WITH OUTLET

Size	White Item Code	Blue Item Code	Red Item Code
140mm	ww14	brw14	rw14
180mm	ww18	brw18	rw18



### ▶ SHORT STOP END

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wss14	bss14	rss14
180mm	wss18	bss18	rss18



### ▶ STOP END OUTLET

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wse14	bse14	rse14
180mm	wse18	bse18	rse18




### ▶ SUPPORT BRACKET

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wsb14	bsb14	rsb14
180mm	wsb18	bsb18	rsb18




### TOP BRACKET

Size	White Item Code	Blue Item Code	Red Item Code
140mm	wtb14	btb14	rtb14
180mm	wtb18	btb18	rtb18



### RAFTER BRACKET TOP

Size	Item Code
140mm	rbt
180mm	rbt



### RAFTER BRACKET SIDE

Size	Item Code
140mm	rbs
180mm	rbs